


1/4 Sheet Palm Sander

5133000348 - EOS2410NHG - EOS2410NHG#1





Position	Quantity	Description	Part number	EAN
001	3	SCREW	5131027995	
002	1	HOUSING COVER	5131027996	
003	1	COVER	5131027997	
004	1	INDICATOR LIGHT	5131027998	
005	1	CAPACITOR EOS2410N	5131002855	
006	1	SWITCH	5131001402	
007	1	TRIGGER	5131027999	
009	2	CARBON BRUSH	5131001403	
010	2	BRUSH HOLDER COMPL.	5131001404	
011	1	TERMINAL PLUG	5131028000	
012	2	SCREW	5131028001	
013	1	CLAMP	5131028002	
014	4	SCREW	5131028003	
018	1	PROTECTION SLEEVE	5131028005	
019	1	CONNECTION CABLE	5131028007	
021	1	SCREW	5131028008	
022	2	WIRE	5131028009	
027	1	FAN	5131000192	
028	1	FAN	5131028010	
029	2	SCREW	5131028011	
030	2	CUSHION EOS2410N	5131002859	
031	2	CLAMP	5131028012	
032	1	BEARING 628Z EOS2410N	5131002860	
033	1	DUST SHIELD EOS2410N	5131002861	
034	1	RUBBER PIN EOS2410N	5131002862	
035	1	SANDING PLATE	5131028013	
036	2	SELF TAPPING SCREW ST M4X7.5	5131002863	
037	2	RETAINING PLATE EOS2410N	5131002864	
038	1	SAND PAD	5131000195	
039	4	SELF TAPPING SCREW ST4X16 EOS2410N	5131002865	
100	1	MOTOR HOUSING	5131028004	
101	1	ARMATURE & FIELD ASSEMBLY EOS2410N	5131002858	
	1	DUST BAG	5131028014	
	1	DUST REFLECTOR	5131028015	
	1	PUNCH	5131028016	
	1	SWISS ADAPTER	5131027809	
	1	SANDER PAPER 120 GRIT EOS2410	5132001444	4960673402821
	1	SANDER PAPER 200 GRIT EOS2410	5132001446	4960673402845
	1	SANDER PAPER 150 GRIT EOS2410	5132001445	4960673402838