


# Cordless Speed Sprayer

5133000155 - P620 - P620#1





Position	Quantity	Description	Part number	EAN
001	1	SWITCH	5131027671	
002	1	MOTOR ASSEMBLY	5131027672	
003	1	GEAR BOX	5131027673	
004	15	SCREW	5131011356	
005	1	SCREW	5131026630	
006	1	SPRING WASHER	5131026624	
007	1	HOUSING SET ASSY	5131027674	
008	1	RETAINING RING	5131026647	
009	1	WASHER	5131026646	
010	1	SPRING	5131026645	
011	1	PIN	5131026644	
012	1	HOOK	5131026643	
013	1	HOLDER	5131026631	
014	1	PISTON	5131026632	
015	1	PRESSURE SPRING	5131026633	
016	1	HOUSING	5131026634	
017	1	FILTER	5131027675	
018	1	TANK	5131026638	
019	1	O-RING	5131027676	
020	1	LOCKING NUT	5131026639	
021	1	VALVE	5131026640	
022	1	ROUND JET NOZZLE	5131027677	
023	1	ROUND JET NOZZLE	5131027678	
024	1	SEALING FELT	5131026629	
025	1	OIL	5131026652	
026	1	BRUSH CLEANER	5131026653	
027	1	CUP	5131020064	
028	1	CUP	5131020123	
	1	SWISS ADAPTER	5131027809	