


[TRAD] 18V Circular Saw with Laser

5133001164 - RWSL1801M - 5133001164#1





Position	Quantity	Description	Part number	EAN
001	1	SCREW	5131030406	
002	1	FLANGE	5131001795	
003	1	CLAMPING FLANGE	5131030407	
004	4	ST SCREW M2.6X10MM CSD4130GN	5131016190	
005	1	COVER PLATE CRS CCS1801DM/LM	5131017870	
006	1	CUTTING GUARD	5131030408	
007	1	TORSION SPRING DIA 1.5MM WIRE CCS18	5131017871	
008	15	SCREW	5131026648	
009	1	SCREW	5131030409	
010	1	DUST EXTRACTION	5131030410	
011	1	BLADE HOUSING	5131030411	
012	1	SCREW	5131030412	
013	1	RUBBER STOP	5131030413	
014	1	LASER-INSTRUMENT	5131030414	
015	1	MOTOR HOUSING	5131030415	
016	2	NUT	5131030416	
017	1	SCREW	5131030417	
018	1	COVER	5131030418	
019	1	CONNECTOR	5131030419	
020	1	SPRING	5131030420	
021	1	SWITCH	5131030421	
022	1	LOCKING PIN	5131030422	
023	1	SPRING SAFETY BUTTON DIA.0.6 OD5.5	5131011719	
024	1	MOTOR AND PINION LCS180	5131006707	
025	1	SCREW CHT1850LC	5131011415	
026	1	GEAR BOX COVER	5131030423	
027	2	SCREW CHT1850LC	5131011415	
028	2	M SCREW ST. M4.0 PH B\ 16MM CCS1801	5131017757	
029	1	LOCK PIN	5131030424	
030	1	SEALING PAD FIBER 3MM CCS1801LM	5131013172	
031	1	HOLDER	5131030425	
033	1	T-HANDLE-KEY	5131029524	
034	1	STOPPER	5131019717	
035	1	SAW TABLE	5131030426	
036	1	TURNING KNOB	5131030427	
037	1	WASHER	5131019735	
038	1	SCREW	5131030428	
	1	SWISS ADAPTER	5131027809	
039	1	EDGE GUIDE	5132002276	4960673120435
	1	CSB150A1 150MM CIRC SAW BLADE EMEA	5132002579	4892210120465